



RUFFWEAR SIZE GUIDE

RUFFWEAR JACKETS & COATS






Dog's Girth
Measurement around widest part of rib cage

XXS	XS	S	M	L	XL
13-17 in 33-43 cm	17-22 in 43-56 cm	22-27 in 56-69 cm	27-32 in 69-81 cm	32-36 in 81-91 cm	36-42 in 91-107 cm

In between sizes: Choose the larger coat for more coverage.

RUFFWEAR DOG COLLARS







Around Dog's Neck
Measurement around neck where collar would comfortably lay

M	L
14-20 in 36-51 cm	20-26 in 51-66 cm



Chain Reaction™ Collar SIZING



Around Dog's Neck
Measurement around neck where collar would comfortably lay

Width of Collar

S

11-14 in
28-36 cm

M

14-20 in
36-51 cm

L

20-26 in
51-66 cm


0.78 in
20 mm

1 in
25 mm

1 in
25 mm



Top Rope™ Collar SIZING



Around Dog's Neck
Measurement around neck where collar would comfortably lay

Width of Collar

S

11-14 in
28-36 cm

M

14-20 in
36-51 cm

L

20-26 in
51-66 cm


0.78 in
20 mm

1 in
25 mm

1 in
25 mm



Headwater™ Collar SIZING



Around Dog's Neck
Measurement around neck where collar would comfortably lay

Width of Collar

M

14-20 in
36-51 cm

L


20-26 in
51-66 cm

1 in
25 mm

1 in
25 mm



Hoopie™ Collar SIZING



Around Dog's Neck
Measurement around neck where collar would comfortably lay

Width of Collar

S

11-14 in
28-36 cm

M

14-20 in
36-51 cm

L

20-26 in
51-66 cm


0.78 in
20 mm

1 in
25 mm

1 in
25 mm



Crag™ Collar SIZING



Around Dog's Neck
Measurement around neck where collar would comfortably lay

Width of Collar

M

14-20 in
36-51 cm

L


20-26 in
51-66 cm

1 in
25 mm

1 in
25 mm



Hoopie™ Collar SIZING



Around Dog's Neck
Measurement around neck where collar would comfortably lay

Width of Collar

S

11-14 in
28-36 cm

M

14-20 in
36-51 cm

L

20-26 in
51-66 cm

0.75 in
20 mm

1 in
25 mm

1 in
25 mm

RUFFWEAR DOG LEASHES



Knot-a-Leash™ SIZING

	S	L
Diameter of Rope	7 mm	10 mm
Length of Leash	5 ft 1.5 m	5 ft 1.5 m



Knot-a-Long™ SIZING

	ONE SIZE
Diameter of Rope	11 mm
Length of Leash	30 in 76 cm



Just-a-Cinch™ SIZING

	ONE SIZE
Diameter of Rope	10 mm
Length of Leash	5 ft 1.5 m



Slackline™ Leash SIZING

ONE SIZE

Width of Webbing	1 in 25 mm
Length of Leash	3.5-6 ft 1.1-1.8 m



Roamer™ Leash SIZING

	M	L
Length When Resting*	5.5 ft 1.7 m	7.3 ft 2.2 m
Length When Extended*	7 ft 2.1m	11 ft 3.4 m
Width of Tubular Webbing	0.78 in 20 mm	1 in 25 mm
Max Size of Waist-Worn Handle	42 in 1 m	42 in 1 m

*with 8 in (20 cm) handle



Flat Out™ Leash SIZING

ONE SIZE

Width of Webbing	1 in 25 mm
Length of Leash	6 ft 1.8 m



RUFFWEAR

Ridgeline™ Leash SIZING

ONE SIZE

Width of Webbing

15 mm

Length of Leash

2.5-4.25 ft

0.75-1.3 m



RUFFWEAR

Double Track™ Coupler SIZING

ONE SIZE

Length of Leash
(per side)

12-19 in

30-48 cm



RUFFWEAR

Quick Draw™ Leash SIZING

ONE SIZE

Stowed Around Neck

Adjustable from
14-22 in (36-56 cm) collar sizes


In Use As Short Leash

20-27 in (51-69 cm) length
(depending on neck adjustment)

RUFFWEAR DOG HARNESSSES



Front Range™ Harness SIZING



Dog's Girth
Measurement around
widest part of rib cage

XXS

13-17 in
33-43 cm

XS

17-22 in
43-56 cm

S

22-27 in
56-69 cm

M


27-32 in
69-81 cm

L/XL

32-42 in
81-107 cm



Web Master™ Harness SIZING



DOG'S GIRTH
measurement around
widest part of rib cage



**DOG'S
GIRTH**

XXS

13-17"
(33-43 cm)

XS

17-22"
(43-56 cm)

S

22-27"
(56-68 cm)

M

27-32"
(68-81 cm)


L/XL

32-42"
(81-106 cm)

Web Master Harness



Load Up™ Harness SIZING



Dog's Girth
Measurement around
widest part of rib cage

XXS

13-17 in
33-43 cm

XS

17-22 in
43-56 cm

S

22-27 in
56-69 cm

M

27-32 in
69-81 cm

L/XL

32-42 in
81-107 cm

In between sizes: Choose the smallest size.

RUFFWEAR ACCESSORIES




Haul Bag™ SIZING

ONE SIZE

Volume
25 L



Palisades Pack™ SIZING



Dog's Girth
Measurement around
widest part of rib cage

S

22-27 in
56-68 cm

M

27-32 in
68-81 cm

L/XL

32-42 in
81-107 cm

Capacity


610 in³ (10 L)

793 in³ (14 L)

1098 in³ (19 L)



Approach Pack™ SIZING



Dog's Girth
Measurement around
widest part of rib cage

Capacity

XXS

13-17 in
33-43 cm

XS

17-22 in
43-56 cm

S

22-27 in
56-69 cm

M

27-32 in
69-81 cm

L/XL

32-36 in
81-91 cm

122 in³ (2 L)

305 in³ (5 L)


549 in³ (9 L)

732 in³ (12 L)

976 in³ (16 L)



Hi & Dry™ Saddlebag Cover SIZING



Dog's Girth
Measurement around
widest part of rib cage

XXS/ XS

13-22 in
33-56 cm

S/M

22-32 in
56-81 cm


L/XL

32-42 in
81-107 cm

Fits Approach Pack™ and Palisades Pack™
Cover size = pack size



Singletrak Pack™ SIZING



Dog's Girth

Measurement around
widest part of rib cage

S

22-27 in
56-69 cm

M

27-32 in
69-81 cm

L

32-42 in
81-107 cm

Capacity

195 in³ (3.2 L)

195 in³ (3.2 L)

195 in³ (3.2 L)



HIGHLANDS BED™ SIZING

**ONE SIZE**

FLAT
STUFFED
WEIGHT

35 x 26"; 1.6" loft (89 x 66 x 4 cm)

12 x 5" (30 x 13 cm)

14 oz (400 g)

Highlands Bed



Mt. Bachelor Pad™ SIZING

M

L

Unrolled

28 x 35 in; 1 in loft
70 x 90 x 2.5 cm

36 x 48 in; 1 in loft
91 x 122 x 2.5 cm

Rolled

7 x 14 in
18 x 35.5 cm

8 x 18 in
20.5 x 45.5 cm



Kibble Kaddie™ SIZING

ONE SIZE

Dimensions

HEIGHT **15.8 in** x WIDTH **9.5 in** x DEPTH **7.9 in**
400mm x 240mm x 200mm

Volume

10 L
42 cups

**RUFFWEAR
DOG BOOTS**



**Ruffwear Boots
TIPS & TECHNOLOGY**



TIPS FOR FITTING RUFFWEAR BOOTS

1. Don't assume large dogs have large paws - measuring is critical to ensure a proper fit!
2. Unlike human footwear, sizes are based on the width of the paw, not the length.
3. Ruffwear boots are designed to fit a dog's anatomy - they're not designed to be worn at a right angle like human footwear.
4. The boots do not need to be pulled up past the carpal pad.



**Bark'n Boot Liners™
SIZING**

Bark'n Boots Size Range	2.0-2.25 in 51-57 mm	2.5-2.75 in 64-70 mm	3.0-3.25 in 76-83 mm
-------------------------	-------------------------	-------------------------	-------------------------



Paw Width
Measurement across widest part of paw when bearing weight

GETTING THE RIGHT SIZE FOR YOUR DOG

1. Have your dog stand on a firm surface.
2. Place a piece of paper under a front paw.
3. Lift dog's opposite front paw so that weight is placed firmly onto the paw being measured.
4. Mark BOTH SIDES of weighted paw at its widest point on the sheet of paper.
5. Measure that distance and choose correct boot size from the figures above. If you are between sizes, choose the smaller size.



Summit Trex™ SIZING



Paw Width

1.5 in 38 mm	1.75 in 44 mm	2.0 in 51 mm	2.25 in 57 mm	2.5 in 64 mm	2.75 in 70 mm	3.0 in 76 mm	3.25 in 83 mm
-----------------	------------------	-----------------	------------------	-----------------	------------------	-----------------	------------------



Paw Width

Measurement across widest part of paw when bearing weight

GETTING THE RIGHT SIZE FOR YOUR DOG

1. Have your dog stand on a firm surface.
2. Place a piece of paper under a front paw.
3. Lift dog's opposite front paw so that weight is placed firmly onto the paw being measured.
4. Mark BOTH SIDES of weighted paw at its widest point on the sheet of paper.
5. Measure that distance and choose correct boot size from the figures above. If you are between sizes, choose the smaller size.



Ruffwear Boot SIZING



Paw Width

2.0 in 51 mm	2.25 in 57 mm	2.5 in 64 mm	2.75 in 70 mm	3.0 in 76 mm	3.25 in 83 mm
-----------------	------------------	-----------------	------------------	-----------------	------------------



Paw Width

Measurement across widest part of paw when bearing weight

GETTING THE RIGHT SIZE FOR YOUR DOG

1. Have your dog stand on a firm surface.
2. Place a piece of paper under a front paw.
3. Lift dog's opposite front paw so that weight is placed firmly onto the paw being measured.
4. Mark BOTH SIDES of weighted paw at its widest point on the sheet of paper.
5. Measure that distance and choose correct boot size from the figures above. If you are between sizes, choose the smaller size.